

Service Manual

Tumble dryer Condensation TRK4850WS-NL

	Model	l
V	ersion	ì

TRK4850WS-NL 8560 485 12000	Page
Technical data	2 - 3
Spare part list	4
Exploded view	5
Wiring diagram	6
Circuit diagram	7
Text/Legend	8 - 13

Date: 07.11.1996

Document-No.: 4812 713 10905

Technical data

-	-				
n	111	20	ne	10	ns
				HL	<i>1</i> 113

Height	85,0	cm
Width	59,5	cm
Depth	60,0	cm

Weight

Gross weight	42	kg
Net weight	40	kg

Surroundings temperature

Max.room temperature	35	.C
Min. room temperature	5	.С

Humidity

Power connection

Voltage	230	V
Frequency	50	Hz
Connected load	2,8	kW
Fuse	16	Α

Drum data

Volume	112	1
Drum speed	57 ± 2	rpm

Airflow

Circulation air flow	180± 20	
Cooling air flow	180± 20	m ³ /h

Capacity of laundry

Cotton max.	5	kg
Easy care max.	2,5	kg

Condenswater evacuation

Condenswater container	3,5	1
Direct connection to the d	rainage	
1. Possibility:	Use a con	nmercially
	available v	vater hose
Inner diameter	8 - 10	mm
Maximum allowable		
length	2,5	m
Maximum height for		
drain outlet	1,0	m
2. Possibility:	Outlet hose for	
	connect in	ito siphon
Spare part number	4812 530	28243
Length of hose	1,5	m

Electrical components

Heating

Туре	1211 K (or	oen coil)
Nominal voltage	230	V
Nominal power		
(1450 + 1050 W)	2500± 5%	óW
Heating resistances:		
Connectin points 8-9		
(1450 W)	32,8± 5%	Ω
Connectin points 8-4		
(1050 W)	45,3±5%	Ω

Thermostats

Fluff thermostat (in heater) TH 1.2

Measurable between	1-3 or 2-3	
Switch on temperature	70+10/-5	.C
Switch off temperature	117+ 4	°C

Gentle thermostat (in heater) TH 1.3

Measurable between	4-7 or 5-7	
Switch on temperature	90± 4	.(
Switch off temperature	105± 2	°(

Technical data

Internal safety thermostat (in heater) TH 1.4

oniy via	heater	resistor
100± 6	.C	
150± 5	.C	
	100± 6	only via heater 100± 6 °C 150± 5 °C

Safety thermostat (on bulkhead) TH 1.5

Switch on temperature	manual reset
Switch off temperature	125± 5 °C

Exhausting thermostat (in airchannel) TH 1.1

Switch on temperature	70± 4	.C
Switch off temperature	85± 3	.C

Timer

Туре	Electronic Timer	
	Eaton SL49WR2	3202
Nominal voltage	230	V
Frequency	47-63	Hz
Rated currents:		
Motor	≤ 6	Α
Heater	≤ 16	Α
Drumlight	≤ 0.1	Α
Pump	≤ 6	Α
Ambient temperat	ture 0 to 75	.C
Storage temperati	ure -25 to 85	.C

Main- and blower motor

Type	1-phase asynchro	nous
Nominal voltage	230	٧
Frequency	50	Hz
Power consumption	on 285± 7%	W
Resistances of co	ils	
Main coil (2-3)	16± 7%	Ω
Auxiliary coil (3-4)	16± 7%	Ω
Rated speed with		
5 kg laundry and		
100% rest humidi	ty 2700	rpm
Capacitor	10± 10%	μF

Condensation pump

Туре		ynchronous
	motor ME	ES 30.95630
Voltage	230	V
Frequency	50	Hz
Resistance	450± 10%	Ω
Nominal current	53	mA
Blocking current	140	mA
Power consuption	14± 2	W .
Speed	3000	rpm
Capacity	$2,6 \pm 1,1$	l/min

Display

BK display	
module Low-5	EATON MV19BT1R2916
No. of LEDs	12
Buttons	- START
	- Gentle
	- Plus
	- Rapid
	- Buzzer
	- Anticreasing extended
Program selector	16 positions integrated
· ·	ON/OFF contact 24V AC

Radio interference filter

Тур	Eichhoff BV 16.350/122
Voltage	230 V
Capacity	0,1 μ F +
	$2x0.015u F X1Y + 1M\Omega$

Spare part list

 Model
 TRK 4850WS-NL


 Service No.
 856048512000


 Version
 856048512000

Pos. No.	12NC Code	Description
004 0	4812 440 18571	Bottom
011 0	4812 500 18054	Foot adjustable
012 0	4812 528 78033	Roll
012 1	4812 520 28039	Shaft front
012 2	4812 520 28041	Shaft rear
021 0	4812 440 18927	Front
022 0	4812 440 18926	Panel, side
024 0	4812 440 18928	Panel, rear
030 0	4812 440 19399	Table top
033 0	4812 440 18568	Plate
041 0	4812 417 18341	Hinge
053 0	4812 440 19336	Plinth metal
053 1	4812 440 18575	Plinth plastic
053 2	4812 417 28042	Lever,fastener plinth
100 0	4812 417 38015	Door
102 0	4812 452 19382	Door,flap
111 0	4812 401 48568	Grip Heatexchanger
131 0	4812 271 38362	Door lock
131 1	4812 417 18797	Cover plate
133 0	4812 417 28054	Pin door
191 0	4812 466 68461	Gasket, door
204 0	4812 466 38009	Protection
220 0	4812 418 18177	Drum CPL.
223 0	4812 418 88017	Drum lifter
261 0	4812 418 78041	Case
271 0	4812 358 18052	Belt
273 0	4812 358 18055	Pulley jokey
275 0	4812 492 68129	Spring
291 0	4812 466 68521	Gasket Drum rear
291 1	4812 466 68519	Gasket Drum front
301 0	4812 452 19381	Control panel
301 1	4812 452 19367	Frame
322 0	4812 452 19389	Insert panel TRK 4850 NL
331 0	4812 413 48222	Knob
331 1	4812 413 48239	Adapter
332 0	4812 276 18259	Button start
332 1	4812 276 18262	Button
332 2	4812 276 18263	Button
344 0	4812 214 78163	Display board
401 0	4812 361 18188	Motor
401 1	4812 401 18226	Clamp Motor
401 2	4812 401 18229	Clamp motor support
420 0	4812 121 18144	Capacitor 10ÜF
421 0	4812 121 18155	Interf.filter
430 0	4812 360 18079	Pump condens water
430 1	4812 466 28104	Gasket
443 0	4812 361 18189	Fan wheel
456 0	4812 259 38169	Heating element 2500W
481 2	4812 323 18001	Shunt
490 0	4812 321 18019	Cable,mains 5m (without plug)
490 0	4812 321 18026	Cable,mains 3m
521 0	4812 310 18369	Power Card-Kit
557 0	4812 271 28209	Thermostat
557 1	4812 530 58069	Gasket
564 0	4812 271 28213	Thermostat


Pos. No.	12NC Code	Description
571 0 571 1 621 1 631 0 631 1	4812 360 58103 4812 360 58102 4812 270 18001 4812 271 38076 4812 360 18076	Valve Valve body Lever for Doorswitch Microswitch Floater
631 2	4812 360 58104	O-Ring
633 1	4812 276 18223	Pin
651 0	4819 134 88106	Lamp E14-220V 15W
652 0	4812 134 28056	Holder,lamp
652 1	4812 134 28055	Cover f. lamp
653 1	4812 134 48213	Light guide on/off
653 2	4812 134 48209	Light guide
653 3	4812 134 48211	Light guide vertical
653 4	4812 134 48212	Light guide horizontal
692 0	4812 480 58067	Grille with humidity sensor
692 1	4812 278 58001	Sensor
740 0	4812 511 48179	Condenser
740 1	4812 310 38184	Frame
740 2	4812 310 38064	Frame
743 0	4812 530 48152	Conveyor
743 1	4812 530 48122	Air guide f.drumlight
743 2	4812 530 48127	Cover bar
743 3	4812 464 48092	Fan box
750 0	4812 418 78044	Tank Condenswater
761 0	4812 480 58071	Filter FLUFF
781 0	4812 530 28243	Hose,draining external 1,5 m
783 0	4812 530 28803	Hose 0,98 m
783 1	4812 530 28745	Hose 1,37 m
783 2	4812 530 28802	Hose 0,73 m
794 0	4812 466 28105	O-Ring
794 1	4812 466 28103	Gasket heater channel
794 2	4812 466 98935	Sealing Heater holder
794 3	4812 466 98936	Sealing
902 2	4812 256 98015	Heating element holder
903 0	4812 532 28028	Clip,fix
903 1	4812 401 18228	Fastener
903 2	4812 401 18195	Clip
910 0	4812 502 38057	Screw Torx 4,2 x 13
912 0	4812 502 48015	Screw
922 0	4812 532 58005	Ring,circlip Triring
932 0	4812 278 18001	Spring
965 0	4812 440 19339	Lid
965 1	4812 462 79651	Cap Frosty


Exploded view





07.11.1996 / Page 6 Doc. No: 4812 713 10905





07.11.1996 / Page 8 Doc. No: 4812 713 10905 Whirlpool Europe Customer Service


SERVICE

Testpoints at display boards

4619 710 25671

Module No.: 12NC 4619 710 25671 and 12NC 4619 710 23601

All names are printed at the PCB!



Testvoltages:

TP6 (at RD19) = GND

TP4 (at RD27) = +5V to GND

TP5 (at RD23) = +24V to GND

Program selector

TP VA <=> VB:

Position OFF 24V AC Position ON 0V

Function of buttons

Function of LEDs

Functions when button available:

) (D)	01
MP/	Start button
MP1	Gentle option
MP2	Plus option
MP3	Rapid option
MP4	Buzzer option
MP5	Anticreasing extendedoption(ACX)

Functions when LEDs available:

Options:	OL2	Gentle LED
	OL3	Plus LED
	OL4	Rapid LED
	OL5	Buzzer LED
	OL6	ACX LED
Faults:	OL8	Fluff-filter failure LED

OL7 Water container LED
Program flow: OL1 Start LED

OL10 Drying LED
OL15 Cool Down LED
OL16 End LED
OL17 ON LED


07.11.1996 / Page 10 Doc. No: 4812 713 10905

Whirlpool Europe Customer Service

SERVICE

Program selector

4619 710 25671



Coding of Bauknecht selector (16 positions)

O = no contact Contact to common: = contact

Position	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
S1	0	•	•	0	0	•	•	0	0	•	•	0	0	•	•	0
S2	0	0	•	•	•	•	0	0	0	0	•	•	•	•	0	0
S4	0	0	0	0	•	•	•	•	•	•	•	•	0	0	0	0
S8	0	0	0	0	0	0	0	0	•	•	•	•	•	•	•	•

07.11.1996 / Page 12 Doc. No: 4812 713 10905 Whirlpool Europe Customer Service

SERVICE

Program Flow Condense Dryer Module 12NC 4619 710 25661

Program phase	Options influenzing program phase	Motor move- ment		Heatir	ng cycle	S	Pump cycle	Humidity measure- ment	Duration	Conditions to go in the next phase
			Cotton	Easy- Care	Time drying	Delicate				
Programming										push start switch
Start delay	ACX	rev-1	-	-	-	-	1 time pumping		1 9 h	push start switch
	other options	no rev.		-	-	-				user IO actions OR
Drying I	GENTLE	rev-3	RCA	RCA	-	•	standard	on	till RH = condense dryeer HT1	delay time over
	RAPID	no rev.	100%	-	•	•	standard	On.	till RH =condense dryer HT1	
	other options	rev-3	RCA	RCA	DHT	DHT	standard	on	till RH = condense dryer HT1	Condense Dryer HT OR duration OR
Drying II	GENTLE	rev-3	GHT	GHT	,	•	standard	on	till RH = condense dryer HT2	timeout 140'
	RAPID	no rev.	100%	•		•	standard	Off	till RH = condense dryer HT2	
	other options	rev-3	RCA	RCA	DHT	DHT	standard	OIL	till RH = condense dryer HT2	Condense Dryer HT
Drying III	GENTLE	rev-3	DHT	DHT	•	•	standard till pumpstop	Off.	till RH target	Condense Dijer iii
	RAPID	rev-3	GHT	-	•	-	standard till pumpstop	Off	till RH target	
	other options	rev-3	GHT	GHT	DHT	DHT	standard till pumpstop	on	till RH target	selected humidity O duration OR
Drying III	PLUS	rev-3	DHT	DHT	•	-	standard till pumpstop	on	6 min for cotton 3 min for all others	timeout 90' (DRII + DRIII together)
Cool down		rev-3	-	1	•	•	1 time pumping		9 min	
Anticreasing I	Buzzer	rev-4						•	10 min	duration
	other options	rev-4							10 min	
Anticreasing II	other options	rev-5							1 h	duration
	ACX	rev-5							1 h	
		rev-1							3 h	duration
		rev-6							8 h	OR
Drying end									unlimited	deselection of ANTICREASING

RCA (Heater Cycle A) = 82"ON / 8"OFF GHT (Gentle Heater Time) = 70" ON / 20"OFF

DHT (Dynamic Heater Time) = 60"ON / 30"OFF

HT 1 = 18% RH

HT 2 = 13% RH RH = Relative Humidity

Reversing type	cw	off	ccw	off	_
rev-1	10	350	10	350	-
rev-2	88	2	88	2	•
rev-3	80	2	6	2	•

Reversing type	cw	off	ccw	off
rev-4	45	45	45	45
rev-5	10	80	10	80
rev-6	10	710	10	710


All times in seconds

07.11.1996 / Page 14 Doc. No: 4812 713 10905 Whirlpool Europe Customer Service

SERVICE

Testpoints at central board

All names are printed at the PCB!



Testvoltages: TP6 (at RD19) = GND

TP4 (at RD27) = +5V to GND TP5 (at RD23) = +24V to GND

Entering the Test Mode

- a) Rotate program selector clockwise to position 1
- b) Push the START switch.
- c) Press option button 'GENTLE' and hold till d) is ready.
- ① Rotate program selector clockwise to position 2 and counterclockwise back to position 1
 ② Rotate program selector clockwise to position 2 and counterclockwise back to position 1
 Actions ① & ② have to be done within 5 sec. (limit controlled by software).
- e) Release GENTLE button.

If the sequence a) - e) is correct te following signal is displayd:

LED group:	Behaviour:				
Alarm LEDs	Flashing alternating				
Program sequence LEDs	Flashing alternating to 'Humidity LEDs'				
Humidity LEDs	Flashing alternating to 'Program Sequence LEDs'				
Option LEDs	OFF				
Display (7-segment)	OFF				
Buzzer signal	3x BEEP				

General: during test program, when the fluff filter thermostat is open, the fluff fault LED is switched ON and keeps being ON after thermostat closing till the end of the test program.

07.11.1996 / Page 16 Doc. No: 4812 713 10905 Whirlpool Europe Customer Service

SERVICE

Start the Service Test Program

- 1. Turn the program selector clockwise into position 4
- 2. Press 'GENTLE' option button.

Leaving the Test Mode / Stop the Service Test Program

The TEST MODE is terminated by pushing the startbutton or interupt the mains supply for more than 60 sec. Turn the program selector out of its current position will stop the testprogram.

After Sales Service Test Program

The test program works sequential, that means the change from one program step to the next has to be done only by request of pushing the 'GENTLE' button!

Every push is receipt by a 'BEEP' of the buzzer

			Test Mode Entered
Program step No. Condenser	Tested component:	Description:	Selector in position 4
1	Motor CW	Motor CW ON	push GENTLE button
2	Heating element Full Power	Motor CW ON	push GENTLE button
		Heating element FULL POWER ON	push GENTLE button
3	Heating element Reduced Power	Motor CW ON	push GENTEE button
		Heater GENTLE POWER ON	
		Heater 70 sec. ON / 20 sec. OFF	push GENTLE button
4	Pump	Pump ON	
5	Float switch	Fill in water till Float Switch switches	↓ push GENTLE button
		When switched: LED float ON	
		PUMP ON	N 1 CONTRACTOR
6	Motor CCW	Motor CCW ON	push GENTLE button push GENTLE button
7	Humidity measurement	Description see below	V
8	Display and Buttons	Description see below	push GENTLE button
			push GENTLE button

07.11.1996 / Page 18 Doc. No: 4812 713 10905 Whirlpool Europe Customer Service

SERVICE

Humidity Measurement Test (Step 7 of test program)

Before test please remove SEH and plug in test cable set part No . 4812 321 28156 and RWE-Tester part No . 4812 069 52922

Max. duration:

no limit

Description:

- Resistors have to be connected at the humidity sensor.
- The electronic control measures the value at the humidity sensor within some seconds.
- LEDs indicate the measured humidity level due to the following table.

Measured level (% RH)	GENTLE LED	Fluff Filter LED	END-LED		Resistances	for RH
< 22% > 21% RH	ON	OFF	OFF			
< 21% > 20% RH	ON	OFF	ON	← ¬	250 kOhm	20.5%
< 20% > 19% RH	ON	OFF	OFF]		
< 19% > 12% RH	OFF	OFF	OFF	Test OK		
< 12% > 11% RH	OFF	ON	OFF]		
< 11% > 10% RH	ON	ON	OFF	-	1130 kOhm	10.5%
< 10% > 9% RH	OFF	ON	OFF]		
9% > RH	OFF	OFF	OFF			
sensor short circuit	OFF	OFF	OFF			· · · · · · · · · · · · · · · · · · ·

Display and Button test (step 8 of test program)

Max. duration:

10 mir

Description:

check of start delay and options buttons and according LED function

Check of start delay:

1. push start delay button 3 times (=> '0' => '1' => '2') to check segments

2. all LEDs / segments according this button are ON

Check of option buttons:

1. push any option button

2. Corresponding LED is on, all other option LEDs keep their status.